


# S3X3 - How to bleed hydraulic brakes.

Tools you need.

Syringe with the correct fitting

Mineral oil red 

Torx TX15

Allen key 5.0MM

Brake cleaner

Cloth

How to bleed hydraulic brakes

Step 1.

Fill up both syringes with mineral oil 



1 / 12

Step 2.

Remove the handlebar by removing the 2 bolts.



When the bolts are removed you can lift up the handlebar. be careful with the wires of the bell and the boost button!!

Flip the handlebar so the bleed nipple faces up.



Step 3.

Remove the TX15 bleed nipple bolt from the caliper. be careful when removing the bolt oil can leak out.





4 / 12

You can prevent oil leaking on the brake pads and disc by covering up the parts with a cloth.

Insert the syringe.



5 / 12

Step 4.

Remove the TX15 bleed nipple bolt from the brake lever.





Insert the syringe.



step 5.

Squeeze in the syringe by the caliper for 75%



When you do this the air will move up to the brake lever in the syringe.





When all air is collected in the top of the syringe at the brake lever, you squeeze in the syringe at the brake lever. Make sure you don't squeeze air in to the system!! Repeat step 5 for 3 times.

Level out the fluid in the syringes.

Squeeze in the brake lever 5 times.

Repeat step 5.

Step 7.

Remove the syringe from the brake lever and mount the bleed nipple bolt.



When removing the syringe hold a cloth under the brake lever, because oil can leak out

Step 8.

Remove the syringe from the brake caliper and mount the bleed nipple bolt.



You can prevent oil leaking on the brake pads and disc by covering up the parts with a cloth.

Step 9.

Clean the caliper and the brake lever with brake cleaner.

Step 10.

Placed back the handlebar, be careful for the wires!

Insert the handlebar bolts and tighten them.





All Done, happy riding!